JAGUAR F-TYPE R/C Children Car Manual

 Backward Forward

•Turn right •Turn left

•Light •Stop



Product Size: 126*65*50 CM

WARNING: Not to be used in traffic.

This product is designed for children age 3+. Original License Counterfeit Investigated

The company has passed the ISO 9001:2008 quality management system certification

SPARE PARTS LIST Handle Rearview mirror Spanner Parts name Windshield Hood Charger Remote control Gasket Car Body Stearing wheel Wheels Wheels cover Nut Screw

I. SUPPORTS FRAME INSTALLATION

Assembly Instructions:

Turn the vehicle over and fix on the supports frame using the screws provided



II. WHEELS INSTALLATION

Please check the different of the wheels (according to the follow photo)



Assembly Instructions: Take off the nuts from the alxe.

Take turn to fix the gasket

(need not put the gasket to inside of the rear wheels), wheels, gasket, nut (fixed by the spanner), small wheels cover.



III. Remote control gearbox installation

Assembly Instructions:

Fix the remote control gearbox by 4 screw.



IV. Windshield and dashboard installation

Fix the windshield on the dashboard, then fix the connect wire on the car body by the plastic plug-in . Take the steering axle through the dashboard, then fix to the car body. (according the photo)



V. Steering wheel installation

Prepare parts: Steering wheel


Assembly Instructions:

Remove the nut and bolt from the steering wheel.

Firmly connect the wires from the steering wheel to the wires from the

wires from the dashboard.

Push the steering wheel onto the steering column, align the holes and lock in place using the nut and bolt.



Assembly Instructions:

Take off the plastic of insulation, red connection to red terminal



WHILE CONNECTING TO THE STORAGER BATTERY TAKE CARE THAT THEY ARE CORRECTLY CONNECTED



VII.Car hood installation

Align the car hood with the car slot and push until full into place.(according the photo)



IX. Rearview Mirror installation

Align the rearview mirrow with the car slot and push until full into place.



VIII. Car seat and handle installation

- Remove the two screws and place the seat into position.(according the photo)
- Reinsert the screws to fix the seat in place.

Align the handle with the car slot and push until full into place.





■ CHARGING PRECAUTIONS

Battery polarity can not be reversed, please ensure the red wire is connected to the red battery terminal and the black wire is connected to the black battery terminal.

Press the power switch to OFF position to turn the power off.

Open the seat,connect the battery plug,red to red.

Never drain battery completely or to a crawling speed,recharge the battery when a decrease in speed and power is noticed warranty will be voided if misuse has occurred.

Battery charging must be done by adults only. Never allow children to charge the battery. A child could be injured by the electricity involved in charging the battery.

Please don't connect the wires to a short circuit.

The charger and the battery are not a toy.Do not allow children to play with the charger and the battery.

Only operate the battery and charger specified according to the manual instructions.

Please don't open the battery and the charger.

Always secure the battery with the bracket.Or battery can be fall out and injure children if vehicle tips over.

The battery must be handled and operated by adults only. The battery is heavy and contains sulfuric acid(electrolyte).

Dropping the battery could result in serious injury.

Before charging the battery check if wear or damage to the battery, charger ,the connectors and other parts .Any damage is found ,the charger should be repaired or replace immediately .Do not use a damaged charger.

It is normal for the adaptor to feel warm during charging, but if the charger feels too hot, stop charging right now and check the battery and adaptor.

■ WHEN CHARGING TURN OFF THE POWER SWITCH

Please charge the battery for 8-10 hours after first use. Subsequent charges should be 6-8 hours but not exceeding 10 hours. If not being used batteries should still be charged at least once a month to keep the cells active.

- 1. Open the cover of charging socket on the car. $\,$
- 2. Plug the charge into the charging socket.
- 3. Plug the other end of the charger into your wall socket.



Batteries are perishable items that are subject to under and overcharging, please observe the charging times.

harge Hole

Implementation of national standards:EN71、EN62115、CE、ROHS

* JAGUAR and the design of the enclosed product are subject to intellectual property protection owned by JAGUAR LAND ROVER LIMITED.

They are used by Jiaxing Dongma Baby Carrier Co.,Ltd.Under license. License: Jiaxing Dongma Baby Carrier Co.,Ltd.

■ TROUBLESHOOTING

Problem:The car will not move

Answer 1: Please make sure the charger has been removed from the car charging point.

Answer 2: The battery is low on charge. Please charge for 6-8 hours but not exceeding 10 hours.

Charge at least once a month to keep the cells active.

- To avoid fuse cut off the power:
- 1. Max:30kgs, overload is forbidden
- 2. Do not drag any item behind this product.
- 3. Do not allow water or other liquids dip the electrical parts.
- 4. Do not change the line system by yourself.

Answer 3: The battery wires are not connected. Please check the connections on the battery terminals are firmly in place.

Answer 4: battery is broken

Please contact the agent or manufacturer

Answer 5: car body wiring has been damaged

Please contact the agent or manufacturer

Answer 6: the motor is damaged

Please contact the agent or manufacturer

Problem: unable to charge

Answer 1: The battery wires not connected. Please check the connections on the battery terminals are firmly in place.

Answer 2: The charger is not inserted in place

Make sure the charger is plugged into the power outlet properly {ensure the power outlet switch turn on}

Answer 3: The charger not working correctly. The charger should feel slightly warm when on charge. Please contact the agent or manufacturer.

■ TROUBLESHOOTING

Problem: The car only runs for a short time

Answer 1: The battery is low on charge. Please charge for 6-8 hours but not exceeding 10 hours

Charge at least once a month to keep the active.

Answer 2: Battery ageing

The battery may need to be replaced depending on its charging history and age.

Problem: The sounds do not work.

Flobletti. The Southus do flot work.

Please ensure the volume is turned up and the MP3 lead is not connected.

The steering wheel sounds will not work when the MP3 is plugged into the car.

Problem: Charger makes a buzzing sound while charging

This is normal.


Problem:Charger overheating

It is normal for the battery and charger to warm slightly during charging. If they feel excessively hot then please check for a current overload or battery short circuit.

■ FUNCTION INSTRUCTION



- 1) MP3 interface
- 2) Volume adjust
- 3) Key start as real car, insert the key and turn it on.
- 4) Power display
- 5) Socket
- 6) Low/High speed
- 7) Manual/Remote control
- 8) Forward/Backward switch A & B) Horn & Music Button



Attach the MP3 lead to your device to play or own music through the car.Please note the steering wheel sounds were not work when the MP3 lead is connected.

■ HOW TO USE THE REMOTE CONTROL

Take off the battery cover screw,open the battery cover.
Put three AA 1.5V remote control battery on.
Battery charging must be done by adults only.
The remote control must be handled and operated by adults only.
non-rechargeable batteries are not to be recharged.
different type of batteries or new and used batteries are not to be mixed batteries are to be inserted with the correct polarity.
exhausted batteries are to be removed from the toy.
rechargeable batteries are only to be charged under adult supervision.
rechargeable batteries are to be removed from the toy before being charged

■ WARNING

WARNING: Vehicle must be charged fully before use.

Failure to do so voids warranty.

Warning:Not to be used in traffic

Please read manual carefully before use.

Adult assembly required.

This toy have no brake

Always wear a helmet and protective clothing when riding.

Continuous adult supervision required when using this product.

Charging the battery can only be done by adult at all times.

Please keep the manual and packaging for future reference as it contains important information.


The instructions for use should bear a reminder that the toy should be used with caution since skill is required to avoid falls or collisions causing injury to the user or third parties.


■ SAFETY PRECAUTIONS

- 01. While riding, adult supervision is required all the time.
- 02. Always wear a helmet when driving.
- 03. Please don't drive near road or on the footpath.
- 04. It is not recommended to drive the vehicle on wet surface or on slope greater than 15-degree.
- 05. It is recommended to drive this vehicle on smooth surface only,
- 06. Please don't driving this vehicle outdoors when it is raining.
- 07. Make sure that the vehicle stop completely before changing direction from
- 08. Please don't allow children to operate the charger or play with the battery 09. Clean the vehicle with a dry cloth only.
- 10. Please follow the correct weight and age limits allowed to drive this vehicle.
- 11. It is prohibited to change the circuit or add other electric parts.12. Adults must teach their children about safe driving procedures.
- 13. Please turn the power off when not in use.
- 14. Check the seat to ensure it has been fitted and secured with a bolt before driving.
- 15. Inspect all wires and connections of the vehicle periodically.
- 16. Charging the battery should only be done by adults.
- 17. Charging plug is located underneath the seat.
- 18. In order to avoid accidents, please ensure the vehicle is safe before driving.
- 19. Please don't let any child touch the wheels or be near them when the car is moving.
- 20. Warranty period is 90 days from the date of purchase.
- 21. Proof of purchase must be given for goods to be returned, repaired or replaced.

■ DISPOSAL OF BATTERY

Disposal of Battery





Do not dispose of lead-acid battery in your regular household trash.

The incineration land filling or mixing of sealed lead-acid batteries with

household trash is prohibited by law.

Return an exhausted battery to your local approved lead-acid battery recycle, Such as a local seller of automotive batteries.

Contact your local waste management officials for other information.

regarding the environmentally sound recycling and disposal of lead-acid batteries.



Thank you for choosing a PlayActive product.
We hope your child will endure many years of fun with this item. If you require any trouble shooting assistance or help on assembly please view our tutorial videos available on our website.

www.playactive.net

⚠ WARNING!

Do not use this vehicle indoors. Using this vehicle in confined areas may cause the vehicle's motors to over load.

If you require any further assistance please contact the outlet you purchased this item from.





Keep remote control away from children as it is for parental use only.